

***When mounting the sloping profiles,
it is important to follow the steps below.***

Included with the mat	<ol style="list-style-type: none"> 1. Sloping profiles, mitered and cut to size 2. PVC Corners for interconnection
You will need during installation:	<ol style="list-style-type: none"> 1. (cordless) drill 2. Aluminium drill and concrete drill 3. Screws and plugs 4. Optional: superglue

STEP 1:

Carefully unpack the packaging. **Note:** the corners of the approach profiles can be sharp because they are miter cut.



STEP 2:

Place the supplied PVC corners in the corners of the profiles and complete the frame.



optionally, superglue can be added to strengthen the connection.

STEP 3:

Drill the frame to the substrate. Drill holes in the aluminum profiles at a distance of approximately 20-25 cm (see photo for position). Then drill the same holes in the floor and fix the frame to the subfloor with plugs and screws.



STEP 4:

It is frame ready where the mat can be placed. Place one side against the frame and carefully unroll the mat completely. Be careful not to damage the frame.

